


Read this user manual before using PIXOFF




Step 1

Turn the red switch from position 0 to 1. (located on top of the machine)



Step 2

Press the green button on the side – wait 10 seconds.



Step 3

Hold the ball in front of the opening of the machine. Let the hot air hit the ball in the same spot until the resin loosens.

CAUTION: Avoid heat directly aimed at the valve of the ball.



REPEAT..

Step 4

Carefully turn the heated area of the ball against the rotating brush and let the brush remove the resin. Repeat step 3 and step 4 until the ball is clean.


CAUTION: Avoid putting too much pressure on the ball against the brush.



Step 5

Press the red button on the side of the machine.

This shuts off the hot air blower and the rotating brush.



Step 6

Turn the red switch from step 1 back from 1 to 0.

This will also shut off the blower on the right side of the machine.

Start

Heating + brushing

Stop



CAUTION - IMPORTANT TO KNOW

PIXOFF must only be used for cleaning handballs.
Do not touch the heated air vent. It may cause burns.
Do not put your fingers near or inside the brush while it rotates.

Children under the age of 15 must not use the PIXOFF.
Do not use the PIXOFF if you have wet hands or feet.

The PIXOFF machine must not be used for heating fluids or to dry off wet materials or other items.

