




Installation guide



Swing Miksi 1


Code: K311-s





No	Σ	Element		
4	32		DIN 125	10x20
21	8		DIN 125	8x16
43	4		DIN 1587	M8
45	4		ISO 7380	M8x30
57	16		DIN 1587	M10
58	1		-	LOCTITE
79	8		ISO 7380	M10x40
153	8		ISO 7380	M10x60







A set of exact tools for assembly product:

- Tools suitable for prepare holes in the surface
- Spirit level

No	ILOŚĆ	ELEMENT
1	1	Poprzeczka nr1
2	1	Poprzeczka nr 2
3	4	Noga nr 1A
4	2	Noga nr 2
5	2	Noga nr 3
6	1	Siedzisko
7	1	Siedzisko gniazdo
8	2	Ostona
9	8	Nakładka
10	1	Poprzeczka nr 3
11	1	Siedzisko



Designation of security zone



Assembly sequence:


- 1/ Making mounting holes.
- 2/ Assembling the crossbars to the legs.
- 3/ Embedding the elements in the mounting holes.
- 4/ Concreting.
- 5/ Seat assembly.

During aseembly, pay special attention to: correct positioning of the posts, tightening all of them screws and fasteners, securing and marking the place of assembly.

Before putting the device into use, check the stability of all elements, remove the safety tapes and check the level and condition of the fall-absorbing surfaces.

Product installation, maintenance and replacement of play equipment components poses a threat to playing chidren, therefore it is necessary to appropriately mark and protection of the installation site. Such protection must guarantee no access to the site carrying out the works both during and after their completion. The main threats are machinery and electrical equipment, deep foundation holes and incomplete sets fun.

During installation, it is required to provide mounting space corresponding to the surface device security zone.



Note:

Height of foundation blocks: 34 cm (for elements anchored at a depth of 74cm)