





- 60x40x30 mm

	PROJECT NAME:	SCALE:	DIMENSION:
	Mounting	1:25	mm
Sportlaan 9, 5683 CS Best, The Netherlands T +31 (0)499 393 540 F +31 (0)499 393 744 E info@aquadrolics.nl www.aquadrolics.nl	DRAWING NR:	FORMAT:	DRAWN BY:
	2.3.1a	A4	KH
	PRODUCT:	DATE:	PROJECTION:
	1110 4004 Helicopter	15-3-2018	

System D

- 1= Product
- 2= Chemical anchor M8
- 3= Nut M8
- 4= Carr. ring M8
- 5= Threaded rod M8
- 6= Carr. ring M10



Sportlaan 9, 5683 CS Best, The Netherlands
T +31 (0)499 393 540 | F +31 (0)499 393 744
E info@aquadrolics.nl | www.aquadrolics.nl

PROJECT NAME:

Mounting

DRAWING NR:

2.3.1b

PRODUCT:

1110 4004 Helicopter

SCALE:

1:8

FORMAT:

A4

DIMENSION:

mm


DRAWN BY:

KH

DATE:

15-3-2018

PROJECTION:







AQUA DROLICS
Mounting system B

Tools:


- drilling machine
- drill (steel) Ø 5 mm
- drill (concrete) Ø 10 mm
- steel brush Ø 11 mm
- pencil
- tape-measure
- wrench nr 10
- wrench nr 13




Determine the position of the product, then draw the contour with a pencil.




Position the PVC blocks at a distance of 8-10 mm from the edge of the product (as shown in drawing 2.3.1)




Drill holes Ø 10 in the sub-soil. Drilling depth is shown in the attached drawing.




Brush the holes with the steel brush (Ø 11 mm). Remove any dust.




Insert capsule.




Insert anchor shaft, using the delivered tool.



Leave the anchor to harden. Afterwards, remove any remains around the shaft.



Mount the PVC blocks with ring and nut. Mark their location outside the outline of the product.



Place the product over the blocks. Drill a hole Ø 5 mm through the product in each of the PVC blocks. Fix the product on the blocks with the bolts Ø 6x50 mm. Put a nylon cap on every bolt.




AQUA DROLICS
Mounting system D-2

Tools:


- Drilling machine
- Mounting system D
- Body ring M8
- Body ring M10
- Concrete drill Ø 10 mm
- Steel brush Ø 11 mm
- Pencil
- Measuring tape
- Wrench nr 13

1




Determine the position of the product.
Mark the outline and position of the
holes on the sub-soil.

2




Drill holes in the sub-soil using the
concrete drill Ø 10 mm.
Depth as shown in the products drawing.

3




Brush the holes using the steel brush (Ø
11 mm).
Clean the holes.

4




Insert capsule.

5




Place anchor shaft using the delivered
tool.

6




Leave the anchor to harden.

7



Remove any remains around the anchor
shaft.

8



Mount the product.

	T=10°C	T=20°C
Harden time dry concrete	40 min.	20 min.
Harden time wet concrete	120 min.	60 min.